



**COMANCHE
OWNER'S HANDBOOK**

WARNING

The rudder pedals are suspended from a torque tube which extends across the fuselage. The pilot should become familiar with the proper positioning of his feet on the rudder pedals so as to avoid interference with the torque tube when moving the rudder pedals or operating the toe brakes.

757 436

COMANCHE

PA-24-180 PA-24-250

Owner's Handbook



**Piper Aircraft Corporation, Lock Haven, Pa.
U. S. A.**

NOTICE

THIS HANDBOOK IS NOT DESIGNED, NOR CAN ANY HANDBOOK SERVE, AS A SUBSTITUTE FOR ADEQUATE AND COMPETENT FLIGHT INSTRUCTION, OR KNOWLEDGE OF THE CURRENT AIRWORTHINESS DIRECTIVES, THE APPLICABLE FEDERAL AIR REGULATIONS, AND ADVISORY CIRCULARS. IT IS NOT INTENDED TO BE A GUIDE OF BASIC FLIGHT INSTRUCTION, NOR A TRAINING MANUAL.

THE HANDBOOK IS DESIGNED:

1. TO HELP YOU OPERATE YOUR COMANCHE WITH SAFETY AND CONFIDENCE.
2. TO MORE FULLY ACQUAINT YOU WITH THE BASIC PERFORMANCE AND HANDLING CHARACTERISTICS OF THE AIRPLANE.
3. TO MORE FULLY EXPLAIN YOUR COMANCHE'S OPERATION THAN IS PERMISSIBLE TO SET FORTH IN THE AIRPLANE FLIGHT MANUAL.

IF THERE IS ANY INCONSISTENCY BETWEEN THIS HANDBOOK AND THE AIRPLANE FLIGHT MANUAL APPROVED BY THE F.A.A., THE AIRPLANE FLIGHT MANUAL SHALL GOVERN.


Revised text and illustrations shall be indicated by a black vertical line in the margin opposite the change.

Additional copies of this manual, Part No. 753 529, may be obtained from your Piper Dealer.

Published by
PUBLICATIONS DEPARTMENT
Piper Aircraft Corporation
753 529

Issued: October 1960

Revised: April 1973



SECTION ONE


DESIGN FEATURES						Page
I.	Specifications	.	.	.	.	5
II.	Engine and Propeller	.	.	.	.	6
III.	Fuselage and Wing Structures	.	.	.	.	7
IV.	Landing Gear	.	.	.	.	8
V.	Control System and Surfaces	.	.	.	.	11
VI.	Fuel System	.	.	.	.	12
VII.	Electrical System	.	.	.	.	14
VIII.	Cabin Features	.	.	.	.	16

DESIGN FEATURES

1. Specifications:

	PA-24 180	PA-24 250
Engine	Lyc. O-360-A	Lyc. O-540-A1A5
HP and RPM	180 at 2700	250 at 2575
Gross Weight (Lbs.)	2550	2800
Empty Weight (Standard) (Lbs.)	1455	1600
Useful Load (Lbs.)	1095	1200
Empty Weight (Custom) (Lbs.)	1485	1630
Useful Load (Custom) (Lbs.)	1065	1170
Empty Weight (Super Custom) (Lbs.)	1530	1675
Useful Load (Super Custom) (Lbs.)	1020	1125
Wing Span (Ft.)	36	36
Wing Area (Sq. Ft.)	178	178
Length (Ft.)	24.7	24.9
Height (Ft.)	7.3	7.3
Propeller Diam. (Max. In.)	74	77
Power Loading (Lbs. per HP)	14.2	11.2
Wing Loading (Lbs. per Sq. Ft.)	14.3	15.7
Baggage Capacity	200	200
Fuel Capacity (Standard, Gals.)	50	60
Fuel Capacity (With Reserve Fuel, Gals.)	60	
Tire Pressure (Lbs.)	Nose 27, Main 27	Nose 27, Main 42
Wheel Base (Ft.)	6.5	6.5
Wheel Tread (Ft.)	9.8	9.8
Top Speed (MPH)	167	190
Cruising Speed		
(75% Power, Sea Level, MPH)	150	171
Optimum Cruising Speed		
(75% Power, Optimum Alt.)	160	181
Stalling Speed (Flaps Down, MPH)	61	64
Take-off Run (Ft.)	750	750
Landing Roll (Flaps Down, Ft.)	600	650
Best Rate of Climb Speed (MPH)	96	95
Rate of Climb (Ft. per Min.)	910	1400
Service Ceiling (Ft.)	18,500	20,000
Absolute Ceiling (Ft.)	21,000	22,000
Fuel Consumption		
(Gal. per Hr., 75% Power)	10	14
Cruising Range		
(75% Sea Level, 50 Gals. Fuel)	5 Hrs., 750 Mi.	
Cruising Range, Optimum (50 Gals. Fuel)	6.2 Hrs., 920 Mi.	
Cruising Range		
(75% Sea Level, 60 Gals. Fuel)	6 Hrs., 900 Mi.	4.3 Hrs., 740 Mi.
Cruising Range, Optimum (60 Gals. Fuel)	7.5 Hrs., 1100 Mi.	7.5 Hrs., 1100 Mi.


Performance figures are for Custom model airplanes flown at gross weight under standard conditions at sea level, or stated altitude. Any deviation from Custom equipment may result in changes in performance.

II. Engine and Propeller:

The Comanche Model 180 is equipped with a Lycoming O-360-A series engine rated at 180 HP at 2700 RPM. The engine in the 250 is a Lycoming O-540-A series, developing 250 HP at 2575 RPM. Both engines have compression ratios of 8.5 to 1, and require 91/96 octane minimum fuel. They are furnished with a geared starter, 35 ampere 12-volt generator, voltage regulator, shielding, fuel pump, propeller governor, vacuum pump drive, and carburetor air box and filter.

The exhaust system on the 180 is a stainless steel cross over type. A large muffler and oversize heater shroud is provided on both the 180 and 250 installations, to supply heat for cabin and carburetor heater systems.

Engine cooling is accomplished without the complication of cowl flaps or exhaust augmenters, and without drag producing fixed cowl flanges.



The 180 uses the Hartzell, model HC92ZK8D or the McCauley, model 2D36C14.


The 250 uses the Hartzell, model HC82XKID. All propellers are constant speed controllable.

III. Fuselage and Wing Structures:

Structures are of sheet aluminum construction, and are designed to ultimate load factors well in excess of normal requirements. All components are completely zinc chromate primed, exterior surfaces are enameled as well.

The main spars of the wings are joined with high strength butt fittings in the center of the fuselage, making in effect a continuous main spar. Main spars are attached to the fuselage at the side of the fuselage and in the center of the structure; wings are attached also at the rear spar and at an auxiliary front spar.

The wing airfoil section is a laminar flow type, NACA642A215, with maximum thickness about 40% aft of the leading edge. This permits the main spar, located at the point of maximum thickness, to pass through the cabin under the rear seat, providing unobstructed cabin floor space ahead of the rear seat.





IV. Landing Gear:

The main wheels are Cleveland Aircraft Products Model 3070, 600 x 6, with single disc hydraulic brakes, Model 3000-250. The nose wheel is Cleveland Model 38501; all wheels have 600 x 6 tires.

The nose gear is steerable through a 40 degree arc through use of the rudder pedals. As the nose gear retracts, the steering linkage disengages to reduce rudder pedal loads in flight. The nose wheel is equipped with a hydraulic shimmy damper.

Many of the parts of the three air-oil type landing gear units, including the forks, struts, and torque links, are interchangeable. All three gears are inflated to approximately $2\frac{3}{4}$ inches of strut extension.

The landing gear is retracted or extended in 7 seconds by an electric motor installed under the front center floorboards, actuating push-pull controls to each of the gears. Manual extension of the



gear is accomplished with the Emergency Gear Lever aft of the nose gear well.

The brakes are actuated by a hand lever and a master cylinder located under the front left floorboards along with the parking brake unit. The brake fluid reservoir is installed on the front left side of the firewall.

To prevent inadvertent retraction of gear on the ground, a switch is installed on the left main gear which cuts off current to the retraction motor until the gear is fully extended. This feature must not be tested during ground operation.

A green light on the instrument panel below the landing gear switch indicates all gears down and locked. An amber light above the switch indicates gears up. These lights are automatically dimmed when the navigation lights are turned on.



V. Control System and Surfaces:

Dual wheel and rudder controls are provided, with cables to control surfaces. The horizontal tail is a stabilator, with an anti-servo tab which also acts as a longitudinal trim tab, actuated with trim crank in the cabin ceiling. The stabilator provides extra stability and controllability with less size, drag and weight than with conventional horizontal tail surfaces.


A rudder trim adjustment is mounted on the right side of the nose wheel dome to permit directional trim as needed in flight.

The flaps are manually operated, balanced for light operating forces and spring loaded to return to the up position. Locks on the inboard ends of the flaps hold them in the up position so that the right flap can be stepped on for entry or exit. The flap will not support a step load except when in the full up position, so must be completely retracted when used as a step.

The flaps have three extended positions, 9, 18 and 27 degrees. Full flap is recommended for landing, zero or partial flap for take-offs.



VI. Fuel System:




Two nylon and neoprene fuel cells in the inboard leading edge sections of the wings provide fuel capacity. The cells should be kept full of fuel during storage of the airplane to prevent accumulation of moisture and deterioration of the cells. For long term storage without fuel, the cells should be coated with light engine oil to keep the rubber from drying out.

Each fuel cell holds a maximum of 30 gallons. On the 180, to obtain the standard fuel quantity of 50 gallons total, or 25 gallons per tank, the cells are filled only to the bottom of the filler neck, which extends into the fuel cell about one inch. To obtain the standard plus reserve quantity, the cells are filled to the top of the filler necks. This system provides a reserve fuel capacity without the necessity for extra tanks, valves and lines.

On the 250 Comanche, 60 gallons is the standard fuel capacity, and the tanks are normally filled to the tops of the filler necks.

An electric auxiliary fuel pump is provided for use in the event



of failure of the standard engine driven pump. The electric pump is normally turned on for landings and take-offs.


The fuel strainer, equipped with a quick drain, is mounted under the right forward section of the fuselage. The strainer should be drained regularly to check for water or dirt accumulations.



The procedure for draining the right and left tanks and lines is to open the gasculator quick drain for a few seconds with the fuel tank selector on one tank. Then change the fuel selector to the opposite tank and repeat the process, allowing enough fuel to flow out to clear the line as well as the gasculator.


VII. Electrical System:

A 12-volt 33 ampere hour battery is mounted behind the baggage compartment in a sealed stainless steel battery box. The standard generator has an output of 50 amperes.

Electrical switches and circuit breakers, located on the lower left instrument panel, control the navigation and instrument lights,







two landing lights, electric turn and bank, and other electrical components. The circuit breakers automatically break the electrical circuit if an overload is applied to the system, preventing damage to electrical wiring. To reset the breakers, simply push in the buttons. Allow approximately two minutes for breakers to cool before resetting.



VIII. Cabin Features:



The instrument panel of the Comanche is designed to accommodate the customary advanced blind flight instruments on the left side in front of the pilot, and the engine instruments on the right side. Provision for extra instruments is made in both sections. Instruments are shock mounted, and are accessible for maintenance by removing a portion of the fuselage cowl over the instruments.

Front seats are adjustable through a long range for pilot comfort and to facilitate entry and exit. They are easily removed by taking out the stops at the end of the mounting tracks and sliding the seats off their tracks.


The rear seat back is adjusted to various fore and aft positions by use of the latches at the outboard upper corners. The entire rear

seat is removed quickly by disengaging the aft seat bottom tube from its attachment clamps, detaching the latches behind the top of the seat back, removing the center safety belt bolt, then lifting both the seat and the back as one unit from the cockpit.





**Ventilating
and
Heating**



1. FRESH AIR INLET
2. FRESH AIR OUTLET
3. HEATER INLET
4. HEATER OUTLET
5. DEFROSTER OUTLET
6. CABIN VENT CONTROL
7. DEFROSTER CONTROL
8. CABIN HEAT CONTROL
9. CABIN VENT CONTROL

↑ CABIN HEATER AIR

▨ CABIN FRESH AIR

SECTION TWO

OPERATING INSTRUCTIONS	Page
I. Preflight	19
II. Starting	19
III. Warm-up and Ground Check	19
IV. Take-off, Climb, Stalls	20
V. Cruising	21
VI. Approach and Landing	22
VII. Emergency Procedures	23
VIII. Mooring	27
IX. Weight and Balance	28
X. Tips	29

OPERATING INSTRUCTIONS

I. Preflight:

Be sure that you have been thoroughly checked out before operating this aircraft.

The following safety procedure instructions must become an integral part of the aircraft owner's operational routine and/or pre-flight inspection.

Before each flight, visually inspect the airplane, and/or determine that:

- (1) The tires are satisfactorily inflated and not excessively worn.
- (2) The landing gear oleos and shock struts operate within limits.
- (3) The propellers are free of detrimental nicks.
- (4) The ground area under propeller is free of loose stones, cinders, etc.
- (5) The cowling and inspection opening covers are secure.
- (6) There is no external damage or operational interference to the control surfaces, wings or fuselage.
- (7) The windshield is clean and free of defects.
- (8) There is no snow, ice or frost on the wings or control surfaces.
- (9) The tow-bar and control locks are detached and properly stowed.
- (10) The fuel tanks are full or are at a safe level of proper fuel.
- (11) The fuel tank caps are tight.
- (12) The fuel system vents are open.
- (13) The fuel strainers and fuel lines are free of water and sediment by draining all fuel strainers once a day.
- (14) The fuel tanks and carburetor bowls are free of water and sediment by draining sumps once a week.
- (15) There are no obvious fuel or oil leaks.
- (16) The engine oil is at proper level.
- (17) The brakes are working properly.
- (18) The radio equipment is in order.
- (19) There is adequate carburetor heat.

(20) The weather is satisfactory for the type of flying you expect to do.

(21) All required papers are in order and in the airplane.

(22) Upon entering the plane, ascertain that all controls operate normally, that the landing gear and other controls are in proper positions and that the door is locked.

II. Starting:

When the engine is cold, (under 40° F.) prime three to five strokes; if extremely cold, pull the propeller through by hand four to six times before turning on the key ignition to "left" and engaging the starter button. The throttle should be open about one-quarter inch for easiest starting. On airplanes equipped with ignition key starter, disregard "left" mag starting instructions.

If the engine does not start in the first few revolutions, open the throttle wide while the engine is turning over with the ignition on. This unloads the engine if it is over-rich. If this procedure does not start the engine, continue to load the cylinders by priming or unload by opening the throttle. If the engine still does not start, check for malfunction of the ignition or fuel system.

When the engine is warm, (over 40° F.) do not prime but turn ignition switch on immediately and engage starter. Warm start priming can be accomplished by pumping the throttle, however care should be taken not to overload the engine this way. It is not necessary to turn the electric fuel pump on for starting.

III. Warm Up and Ground Check:

As soon as the engine starts, the oil pressure should be checked. If no pressure is indicated within thirty seconds, stop the engine and determine the trouble.

Warm up the engine at 800 to 1200 RPM for not more than two minutes in warm weather, four minutes in cold weather. If electrical power is needed from the generator, the engine can be warmed up at 1200 RPM at which point the generator cuts in. The magnetos should be checked at 2000 RPM, the drop not to exceed 125 RPM with manifold pressure of .15" HG. The engine is warm enough for take off when the throttle can be opened without the engine faltering.

Carburetor heat should be checked during the warm up to make sure the heat control operation is satisfactory and to clear out the carburetor if any ice has formed. It should also be checked

in flight occasionally when outside air temperatures are between 20°F and 70°F to see if icing is occurring in the carburetor. In most cases when an engine loses manifold pressure without apparent cause, the use of carburetor heat will correct the condition.

When carburetor heat is applied, cold air entering the induction system is taken from a rear baffle to an exhaust pipe shroud, then to the carburetor; it is not filtered. For this reason carburetor heat should not be used on the ground in dusty conditions except momentarily during the run-up. Dust taken into the intake system can damage the engine severely, and caution must always be exercised during ground operation to prevent dust from entering the engine.

The propeller control should be moved through its normal range during the warm up to check for proper operation, then left in the full high RPM position.

During the propeller check as during other ground operation, care must be taken not to run-up the engine with the propeller over loose stones, cinders or other objects which can be picked up by the propeller, and which frequently cause extensive damage to the propeller blades.

IV. Take-Off, Climb and Stalls:

Just before take-off the following should be checked:

- | | |
|--------------------|----------------------------|
| (1) Controls free. | (6) Carburetor heat off. |
| (2) Flaps up. | (7) Fuel on proper tank. |
| (3) Tab set. | (8) Electric fuel pump on. |
| (4) Propeller set. | (9) Engine gauges normal. |
| (5) Mixture rich. | (10) Door latched. |

After the take-off has proceeded to the point at which a landing can no longer be made wheels down in the event of power failure, the wheels should be retracted. For maximum rate of climb, the propeller and throttle controls should be left at take-off power. For reduced power climbs, the RPM can be reduced to 2400 or 2500 RPM, with full throttle, or manifold pressure can be reduced as desired.

The best rate of climb is obtained at 96 MPH indicated airspeed at sea level on the 180, 95 MPH on the 250. This speed should be decreased about 1 MPH per thousand feet of altitude, so that at 10,000 feet, the best airspeed for maximum rate of climb is 86 MPH. A good rate of climb is obtained at lower altitudes at 100 to 110 MPH, while forward speed is increased. Reducing the climb-

ing airspeed below 95 MPH at low altitudes has the added disadvantage of cutting down forward visibility, so no speeds below that figure are recommended.

The gross weight stalling speed of the two Comanche models with full flaps is 61 and 64 MPH respectively. The stall speed increases about 5 MPH with flaps up. All controls are effective at speeds down to the stalling speed, and stalls are gentle and easily controlled.

V. Cruising:

The cruising speed of the Comanche models is determined by many factors including power setting, altitude, temperature, load, and equipment installed on the airplane.

For the 180 Comanche, the normal recommended cruising speed is 160 MPH at 75% power at 8000 feet altitude. This power setting is obtained under standard conditions at 2400 RPM and about 22" M. P. Fuel consumption at this speed approximates 10 gallons per hour. This gives a cruising range with standard fuel of 5 hours or 800 miles, and with reserve fuel 6 hours or 960 miles.

The 250 Comanche has a maximum recommended cruising speed of 181 MPH at 75% power at 7000 feet, 2400 RPM and 22.6" M. P. With a fuel consumption of 14 gallons per hour, this cruising condition gives a range of 4.3 hours or 785 miles.

To keep engine wear, fuel consumption, and noise at reasonable levels, cruising RPM's from 2100 to 2400 are recommended, with appropriate Manifold Pressures to obtain power settings of 65% to 75% power at low and intermediate altitudes.

With the Hartzell propeller installation on the 180 HP engine, Manifold Pressures of more than 23.5" should not be used at less than 2250 RPM to avoid undesirable propeller stresses. Otherwise, there are no power setting limitations on this installation. In the case of the McCauley propeller, cruising at 2450 RPM or higher with Manifold Pressures over 24.5" must be avoided. This induces no operational handicap because these power settings are too high (over 80% power) to be practical. With this installation, Manifold Pressures over 25" should not be used at less than 2100 RPM.

For minimum fuel consumption and maximum efficiency, the best power settings during cruising flight are with minimum RPM and the necessary Manifold Pressures to obtain a given percent of power, consistent with the above limitations. Engine smoothness and noise level should be major factors in determining the best RPM.

Use of the mixture control in cruising flight reduces fuel consumption significantly, especially at higher altitudes. The mixture should always be leaned during cruising operation over 5000 feet altitude, and normally also at lower altitudes at the pilot's discretion.

The continuous use of carburetor heat during cruising flight increases fuel consumption and reduces power and performance. Unless icing conditions in the carburetor are severe, do not cruise with the heat on. Apply full heat only for a few seconds at intervals determined by icing severity.

In order to keep the airplane in best lateral trim during cruising, the fuel should be used alternately from each tank. On the 180 Comanche, it is recommended that one tank be used for one hour after take off, then the opposite tank used for two hours, and then the first tank until the fuel runs completely out. This will take approximately two hours if the tanks were full, including the reserve quantity, at take off, and will leave about one more hour's fuel left in the second tank. On the 250, a similar procedure should be used keeping the fuel load in an approximate balance to avoid wing heaviness.

VI. Approach and Landing:

During the approach, the landing gear can be lowered at speeds under 150 MPH, preferably on the downwind leg. The flaps can be lowered at speeds of up to 125 MPH, if desired. For final approach, trim the aircraft to approximately 85 MPH (PA-24-180), 90 MPH (PA-24-250) with full flaps, or approximately 90 MPH (PA-24-180), 95 MPH (PA-24-250) with no flaps. The propeller should be set at high RPM to facilitate an emergency go-around if needed. Carburetor heat generally is not applied during landing unless icing conditions are suspected. If a landing is aborted move the carburetor heat to the off position immediately if full power is desired.

The amount of flap used during landings and the speed of the aircraft at contact should be varied according to the wind, the landing surface, and other factors. It is always best to contact the ground at the minimum practicable speed consistent with landing conditions.

Normally, the best technique for short and slow landings is to use full flap and a small amount of power, holding the nose up as long as possible before and after ground contact. In high wind conditions, particularly in strong crosswinds, it may be desirable to approach the ground at higher than normal speeds, with partial or no flap.

Maximum braking effect during short landings can be obtained by holding full back on the control wheel with flaps up while applying brakes. This forces the tail down and puts more load on the main wheels, resulting in better traction.

Landing Check List:

- (1) Mixtures rich.
- (2) Propeller set.
- (3) Carburetor heat off (unless icing conditions exist).
- (4) Electric fuel pump on.
- (5) Fuel selector on proper tank.
- (6) Landing gear down (under 150 MPH, check green light on, warning horn off, gear emergency handle in forward position).
- (7) Flaps down (under 125 MPH).

VII. Emergency Procedures:


Emergency landing gear extension is accomplished with the telescoping manual extension lever. This control can be used only to extend the gear if the electrical actuating system has failed, and not to retract the gear manually without the use of the electric motor. With the electric motor disengaged from the gear torque tube, as required in extending the gear manually, there is no mechanism for holding the gear in the up position, so that the gear will not stay up if retracted manually.

To extend the gear, remove the cover over the emergency disengage control, located between the two front seats, and follow the instruction on the back of this cover, as follows:

- (1) Airspeed not over 100 MPH.
- (2) Landing gear switch in center "off" position.
- (3) Disengage electric motor by pushing motor release arm forward through full travel.
- (4) Pull out emergency extension handle to full length.
- (5) Push handle forward full travel to extend landing gear.

If it should become necessary to extend the gear manually, at the completion of the flight the trouble should be determined with the airplane on jacks. Then to return to normal electrical gear operation, re-engaging the electric motor to the landing gear extension torque tube should be done as follows:


- (1) Landing gear switch in center "off" position.



- (2) Pull landing gear emergency extension handle about half way back, allowing gear to hang partially retracted.
- (3) With landing gear control switch, move end of the electric motor drive shaft into position about half way back, so that the slot in the drive shaft is near the mating pin on the torque tube.
- (4) Using the extension handle, move the torque tube pin slightly back and forth until it can be engaged with the drive shaft slot, then push the parts together.
- (5) Lock the drive shaft to the torque tube by pulling the motor release arm full back to the normal locked position.
- (6) Safety-wire the release arm in the locked position.

Gear-Up Landing:

A gear-up landing should only be made during an emergency (1) when the surface is too soft or rough to permit a gear down landing, (2) when a field is too short for a gear-down landing, which



might cause more damage through hitting obstructions than the gear-up landing would cause, (3) when a water landing is necessary.

In the event of a gear-up landing, make a normal approach as with gear down, leave flaps up (to reduce flap and wing damage), close the throttle and cut the master and ignition switches during the flare out, turn the fuel selector off, and contact the ground at minimum speed.

Engine Failure:

The most common cause of engine failure is mismanagement or malfunction of the fuel system. Therefore, the first step to take after engine failure is to move the fuel selector valve to the tank not being used. This will often keep the engine running even if there is no apparent reason for the engine to stop on the tank being used.

If changing to the opposite fuel tank does not restore the engine:


- (1) Check fuel pressure and turn on electric fuel pump, if off.
- (2) Push mixture control to full rich.
- (3) Apply carburetor heat.
- (4) Check ignition switch.



VIII. Mooring:

The Comanche should be moved on the ground with the aid of the nose wheel-tow-bar provided with each plane and installed in the baggage compartment on the bottom of the hat shelf.

Tie-down ropes for mooring the airplane can be fastened to the wing tie-down rings and the tail skid.

The aileron and elevator controls should be secured by means of the safety belt to prevent control surface damage. The rudder is






held in position by its connections with the steerable nosewheel and does not need to be secured except under unusually high wind conditions. The flaps are locked in position when left full up, so should always be retracted for mooring to prevent wind damage and permit using the flap as a step.

IX. Weight and Balance:

For weight and balance data, see the Flight Manual and Weight and Balance form supplied with each airplane, which gives the exact weight of the airplane and permissible center of gravity conditions.



X. Operating Tips:

In the operation of the Comanche, as in that of any other type of aircraft, there are a few points of technique and information that apply particularly to this model. The following Operating Tips may be helpful in the operation of the Comanche:

(1) Remember that when the navigation lights are on the gear position lights are very dim.

(2) Learn to trim the airplane for take-off so that only a very light back pressure on the wheel is required to lift the ship off the ground.

(3) On take-off, do not retract the gear prematurely. The aircraft may settle and make contact with the ground because of lack of flying speed, atmospheric conditions or rolling terrain.

(4) The best speed for take-off is at about 65 MPH under normal conditions. Trying to pull the airplane off the ground at too low an airspeed will increase the take-off roll rather than decrease it.

(5) Although it is permissible to extend the landing gear at speeds up to 150 MPH, the loads on the landing gear extension motor and on the gear doors are much lower if slower speeds are used. For this reason, it is recommended that unless there is good reason to lower the gear at a higher speed, it should normally be extended at speeds below 125 MPH.

(6) The flaps can be lowered at airspeeds up to 125 MPH. To reduce flap operating loads, however, it is desirable to slow the airplane to 100 MPH or less before extending the flaps. At these reduced speeds, the load that the pilot must apply to the flap lever is very light.

(7) During gear operation, keep the floor area under the emergency gear lever clear. Restriction to movement of the lever will cause the gear motor circuit breaker to open.

(8) Always ascertain position of landing gear by the position of the emergency gear lever as well as the gear position lights.


(9) If, under unusual circumstances, the landing gear motor is apparently being overloaded and the circuit breaker opens repeatedly, the electric motor can be assisted by applying light hand pressure to the emergency gear lever.

(10) Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.

(11) When landing and upon making contact with the ground on the rear wheels, neutralize the rudder pedals, apply additional back pressure to the control wheel and retract the flaps. This gives best directional control on the ground and provides for full effectiveness of the brakes during the landing roll.


SECTION THREE		Page
PERFORMANCE CHARTS		31-38
POWER CHARTS		39-40
POWER TABLES		41-42

PIPER COMANCHE
PA24 180 H.P., 250 H.P.




PIPER COMANCHE

PA24, 180 H.P.




PIPER COMANCHE

PA24, 250 H.P.




PIPER COMANCHE

PA24, 180 H.P.




PIPER COMANCHE

PA24,250H.P.



PIPER COMANCHE


PA24, 180 H.P.




PIPER COMANCHE

PA24, 250 H.P.


RATE OF CLIMB VS STANDARD ALTITUDE




PIPER COMANCHE
PA24 180 H.P., 250 H.P.



Power Chart, Lycoming O-360-A



Power Chart, Lycoming O-540-A



Power Setting Table — Lycoming Model O-360-A, 180 HP Engine

Press. Alt. 1000 Feet	Std. Alt. Temp. °F	99 HP — 55% Rated Approx. Fuel 7.4 Gal./Hr. RPM AND MAN. PRESS.				117 HP — 65% Rated Approx. Fuel 8.8 Gal./Hr. RPM AND MAN. PRESS.				135 HP — 75% Rated Approx. Fuel 10 Gal./Hr. RPM AND MAN. PRESS.			
		2100	2200	2300	2400	2100	2200	2300	2400	2200	2300	2400	
SL	59	20.9	20.3	19.8	19.3	23.3	22.7	22.1	21.5	25.1	24.5	23.9	
1	55	20.7	20.1	19.6	19.1	23.1	22.4	21.8	21.3	24.8	24.2	23.6	
2	52	20.4	19.8	19.3	18.8	22.8	22.1	21.6	21.0	24.6	24.0	23.4	
3	48	20.2	19.6	19.1	18.6	22.5	21.9	21.3	20.8	24.3	23.7	23.2	
4	45	19.9	19.3	18.9	18.4	22.3	21.6	21.1	20.6	24.0	23.5	22.9	
5	41	19.7	19.1	18.7	18.2	22.0	21.4	20.9	20.3	23.8	23.2	22.7	
6	38	19.5	18.9	18.4	18.0	21.8	21.1	20.6	20.1	—	23.0	22.5	
7	34	19.3	18.7	18.2	17.8	21.5	20.9	20.4	19.9	—	—	22.2	
8	31	19.0	18.4	18.0	17.6	21.3	20.7	20.2	19.7				
9	27	18.8	18.2	17.8	17.4	—	20.4	20.0	19.5				
10	23	18.6	18.0	17.6	17.2	—	—	19.8	19.3				
11	19	18.4	17.8	17.4	17.0	—	—	—	19.1				
12	16	18.2	17.6	17.2	16.8								
13	12	—	17.4	17.0	16.7								
14	9	—	—	16.8	16.5								
15	5	—	—	—	16.3								

To maintain constant power, correct manifold pressure approximately 0.17" Hg for each 10° F. variation in carburetor air temperature from standard altitude temperature. Add manifold pressure for air temperatures above standard; subtract for temperatures below standard.

Power Setting Table — Lycoming Model O-540-A, 250 HP Engine

Press. Alt. 1000 Feet	Std. Alt. Temp. °F	138 HP — 55% Rated Approx. Fuel 10.3 Gal./Hr. RPM AND MAN. PRESS.			163 HP — 65% Rated Approx. Fuel 12.3 Gal./Hr. RPM AND MAN. PRESS.			188 HP — 75% Rated Approx. Fuel 14.0 Gal./Hr. RPM AND MAN. PRESS.		
		2100	2200	2300	2400	2100	2200	2300	2400	2400
SL	59	21.6	20.8	20.2	19.6	24.2	23.3	22.6	22.0	24.3
1	55	21.4	20.6	20.0	19.3	23.9	23.0	22.4	21.8	24.1
2	52	21.1	20.4	19.7	19.1	23.7	22.8	22.2	21.5	23.8
3	48	20.9	20.1	19.5	18.9	23.4	22.5	21.9	21.3	23.6
4	45	20.6	19.9	19.3	18.7	23.1	22.3	21.7	21.0	23.3
5	41	20.4	19.7	19.1	18.5	22.9	22.0	21.4	20.8	23.0
6	38	20.1	19.5	18.9	18.3	22.6	21.8	21.2	20.6	22.8
7	34	19.9	19.2	18.6	18.0	22.3	21.5	21.0	20.4	—
9	27	19.4	18.8	18.2	17.6	—	21.3	20.7	20.1	—
8	31	19.6	19.0	18.4	17.8	—	—	20.5	19.9	—
10	23	19.1	18.6	18.0	17.4	—	—	—	19.6	—
11	19	18.9	18.3	17.8	17.2	—	—	—	—	—
12	16	18.6	18.1	17.5	17.0	—	—	—	—	—
13	12	—	17.9	17.3	16.8	—	—	—	—	—
14	9	—	—	17.1	16.5	—	—	—	—	—
15	5	—	—	—	16.3	—	—	—	—	—

To maintain constant power, correct manifold pressure approximately 0.17" Hg for each 10° F. variation in carburetor air temperature from standard altitude temperature. Add manifold pressure for air temperatures above standard; subtract for temperatures below standard.

SECTION FOUR

GENERAL MAINTENANCE

	Page
I. Leveling and Rigging	43
II. Tire Inflation	43
III. Battery Service	44
IV. Brake Service	45
V. Landing Gear Service	45
VI. Fuel Requirements	47
VII. Care of Air Filter	49
VIII. Care of Windshield and Windows	50
IX. Serial Number Plate	50
X. Warranty	51

GENERAL MAINTENANCE

I. Leveling and Rigging:

Leveling the Comanche for purposes of reweighing or rigging is accomplished as follows:

(1) Partially withdraw two machine screws located on the side of the fuselage over the baggage door. These screws are leveling points and the airplane is longitudinally level when a level placed on the head of these screws indicates level.

(2) To put the airplane in a longitudinally level position on scales, first block the main gear oleos to full extension, then deflate the nose wheel tire until the proper position is reached. For rigging purposes only, place airplane on jacks.

(3) To level the airplane laterally, place a level across the floorboard at station 136.5 bulkhead (in baggage compartment between rear spar attachment points).

Rigging: Although the fixed flight surfaces on the Comanche obviously cannot be adjusted in position for rigging purposes, it may be necessary on occasion to check the position of these surfaces. The movable surfaces, with the exception of the flaps, all have adjustable stops as well as adjustments on their cables or push-pull connections, so that their range of movement can be altered. The positions and travels of the various surfaces are as follows:

(1) Wings: 5° dihedral, no twist.

(2) Stabilator: No dihedral, travel 13° up, 5° down, $\pm 1^{\circ}$.

(3) Fin: Should be vertical and in line with center of fuselage.

(4) Ailerons: Travel 19° up, 15° down, $\pm 1^{\circ}$.

(5) Flaps: Travel 27° down in three 9° increments.

(6) Rudder: Travel 25° left or right, $\pm 2^{\circ}$.

For purposes of changing the lateral trim, a fixed tab is provided on the left aileron which can be adjusted as necessary.

II. Tire Inflation:

For maximum service from the tires on the Comanche, keep tires inflated to the proper pressure of 27 lbs. on all three tires on the Comanche 180, and 42 lbs. on the main wheels and 27 lbs. on the nose wheel on the Comanche 250. Interchange the tires on the wheels if necessary to produce even wear. All wheels and tires are balanced before original installation, and the relationship of tire, tube and


wheel should be maintained whenever possible upon reinstallation. Out of balance wheels can cause extreme vibration in the landing gear during take off. In the installation of new components, it may be necessary to rebalance the wheels with the tires mounted.

III. Battery Service:

Access to the 12-volt 33-ampere hour battery is through the right rear baggage compartment panel. The stainless steel box has a plastic drain tube which is normally closed off with a clamp, and which should be opened occasionally to drain off any accumulation of liquid.

The battery should be checked frequently for proper fluid level, but must not be filled above the baffle plates. All connections must be clean and tight.

If the battery is not up to proper charge, recharge starting with a charging rate of 4 amps, and finishing with 2 amps. Quick charges are not recommended.



IV. Brake Service:

The brake system is filled with Univis No. 40 (petroleum base) hydraulic brake fluid. This should be checked at every 100 hour inspection and replenished when necessary, refilling the brake reservoir on the firewall to the indicated level.

No adjustment of brake clearances is necessary on the Comanche brakes. If after extended service the brake blocks become worn excessively, they are easily replaced with new brake segments.


Main wheels are easily removed by taking off the hub caps, axle nut, and removing four bolts from the brake assembly after which the wheels slip freely from the axles.

Tires are dismounted from the wheels by deflating the tube, then removing the wheel through-bolts, allowing the wheel halves to be separated.

V. Landing Gear Service:


In jacking up the Comanche for landing gear and other service, a jack kit (available through the Piper Aircraft Distributor Service Departments) should be used. This kit includes two hydraulic jacks and a tail support. Approximately 300 lbs. of ballast should be placed on the base of the tail support before jacking up the airplane.





Landing gear oleos on the Comanche should be serviced according to instruction on the units. All three oleos should be extended until about $2\frac{3}{4}$ " of oleo piston tube is exposed.

To add air to the oleo struts, a strut pump is attached at the air valve and the oleo pumped up to the proper position. To add oil, first release the air through the valve, allowing the oleo to compress fully. Next remove the air valve core and fill the unit through this opening. Then compress the oleo to within $\frac{1}{4}$ " of full compression,




allowing air and excess oil to escape. Then reinsert the valve core and pump up the strut.

VI. Fuel Requirements:


Aviation Grade 91/96 Octane (minimum) fuel must be used in the Comanche. The use of lower grades of fuel can cause serious engine damage in a very short period of time, and is considered of such importance that the engine warranty is invalidated by such use.

The oil capacity of the Lycoming 0-360-A is 8 quarts, and the minimum safe quantity is 2 quarts. For the 0-540-A, the capacity is 12 quarts and the minimum safe quantity $2\frac{3}{4}$ qts. The operating oil level is normally kept a quart or more below the maximum to reduce oil consumption. It is recommended that engine oil be changed every 50 hours, or sooner under unfavorable conditions. The following grades are required for the specified temperatures:


Temperatures above 40°F	S. A. E. 50
Temperatures between 10°F and 40°F	S. A. E. 30
Temperatures below 10°F	S. A. E. 20



1. FUEL STRAINER
2. FUEL SELECTOR
3. LEFT FUEL TANK
4. ENGINE DRIVEN PUMP
5. CARBURETOR
6. ELECTRIC FUEL PUMP
7. RIGHT FUEL TANK



FUEL SYSTEM COMANCHE



VII. Care of Air Filter:

The air carburetor filter must be cleaned at least once every fifty hours and depending on the type of condition existing, it may be necessary to clean the filters daily or every five hours. Extra filters are inexpensive and should be kept on hand and used for rapid replacement.

The following cleaning procedure is recommended by the manufacturer of the filter:

- (1) Remove air scoop.
- (2) Remove filter from carburetor air box.
- (3) Tap gently to remove dirt particles. Do not use compressed air.
- (4) Reassemble to carburetor air box and replace scoop.

VIII. Care of Windshield and Windows:

A certain amount of care is required to keep the plexiglas windows clean and clear. The following procedure is recommended:

(1) Flush with clean water and dislodge excess dirt, mud, etc., with your hand.

(2) Wash with mild soap and warm water. Use a soft cloth or sponge. (Do not rub).

(3) Remove oil, grease or sealing compounds with a cloth soaked in kerosene.

(4) After cleaning, apply a thin coat of hard polishing wax. Rub lightly with a soft dry cloth.

(5) A severe scratch or mar can be removed by using jeweler's rouge to rub out scratch, smooth on both sides and apply wax.

IX. Serial Number Plate:

The serial number plate on the Comanche is located on the inside of the baggage door. The serial number of the plane should always be used in referring to the airplane in service or warranty matters.