


Revised text and illustrations shall be indicated by a black vertical line in the margin opposite the change.

Published by
PUBLICATIONS DEPARTMENT
Piper Aircraft Corporation
753 696

Issued: July 1965
Revised: December 1972

PIPER



COMANCHE "B"
OWNER'S HANDBOOK


the

COMANCHE 'B'

PA-24-260

Owner's Handbook

PIPER



**Piper Aircraft Corporation, Lock Haven, Pa.
U. S. A.**

**Additional copies of this manual, Part No. 753 696,
may be obtained from your Piper Dealer.**

**Published by
PUBLICATIONS DEPARTMENT
Piper Aircraft Corporation**

753 696

Issued: July 1965

Revised: July 1967



SECTION I

SPECIFICATIONS

Performance	1
Weights	2
Power Plant	2
Fuel	2
Baggage	2
Dimensions	3
Landing Gear.	3

SECTION I

SPECIFICATIONS

PERFORMANCE

Performance figures are for standard PA-24-260 airplanes flown at gross weight under standard conditions at sea level or stated altitude. Any deviation from standard equipment may result in changes in performance.

Take-off Ground Run (ft.)	1260
Take-off Ground Run (ft.) (short field)	760
Take-off Run over 50 ft. barrier	1725
Best Rate of Climb Speed (mph)	111
Best Rate of Climb (ft. per min.)	1370
Best Angle of Climb Speed (mph)	87
Service Ceiling (ft.)	20,000
Absolute Ceiling (ft.)	21,400
Top Speed (mph)	194
Cruising Speed (75% power at sea level) (mph)	171
Optimum Cruising Speed (75% power at 7000 ft.) (mph)	182
Stalling Speed (gear and flaps down) (mph)	67
Stalling Speed (gear and flaps up) (mph)	75
Landing Ground Roll (ft.) *	925
Landing Ground Roll (short field) (ft.) *	655
Landing distance over 50 ft. barrier (ft.) *	1435
Fuel Consumption (2400 rpm 75% power) (gph)	14.1
Fuel Consumption (2400 rpm 65% power) (gph)	12.7
Cruising Range (75% power at 7000 ft.) (mi.)	1108#
Cruising Range (65% power at 10,800 ft.) (mi.)	1190#
Cruising Range (55% power at 15,400 ft.) (mi.)	1230#

* 86 GAL. AVAILABLE FUEL

* AT MAX. LANDING WEIGHT 2945 LB.

WEIGHTS

Maximum Take-off Weight	3100
Maximum Landing Weight	2945
Empty Weight (Standard) (lbs.)	1728
USEFUL LOAD (Standard) (lbs.)	1372

POWER PLANT

Engine (Lycoming)	*O-540-E or **IO-540-D
Rated Horsepower	260
Rated Speed (rpm)	2700
Bore (inches)	5.125
Stroke (inches)	4.375
Displacement (cubic inches)	541.5
Compression Ratio	8.5:1
Dry Weight (pounds)	*397/**402

FUEL

Fuel Capacity (gal.) (Standard)	60
Fuel Capacity (gal.) (With Reserve)	90
Unuseable Fuel (Inboard tanks only) (gal.)	4
Fuel Aviation Grade (Min. Octane)	91/96
Oil Capacity (qts.)	12

BAGGAGE

Maximum Baggage (lbs.)	250
Baggage Space (cubic ft.)	20
Baggage Door Size (in.)	19 x 21

* CARBURETOR INDUCTION ENGINE


** FUEL INJECTION ENGINE

DIMENSIONS

Wing Span (ft.)	35.98
Wing Area (sq. ft.)	178
Length (ft.)	25.29
Height (ft.)	7.47
Wing Loading (lbs. per sq. ft.)	17.42
Power Loading (lbs. per HP)	11.92
Propeller Diameter (in.)	77

LANDING GEAR

Wheel Base (ft.)	6.55
Wheel Tread (ft.)	9.66
Tire Pressure (psi)	Nose 27
	Main 42
Tire Size	Nose (four ply rating) 600 x 6
	Main (six ply rating) 600 x 6



SECTION II

DESIGN INFORMATION

Engine and Propeller	5
Induction System	6
Structures	7
Landing Gear	7
Control System	9
Fuel System	10
Electrical System	13
Heating and Ventilating System	15
Vacuum System	17
Instrument Panel	17
Seats	19
Baggage Area	19
Finish	20

SECTION II

DESIGN INFORMATION

ENGINE AND PROPELLER

The Comanche 260 is powered by a Lycoming O-540-E, carburetor induction engine or a Lycoming IO-540-D, fuel injection engine. Both engines are rated at 260 HP at 2700 RPM, with a compression ratio of 8.5 to 1 and require 91/96 minimum octane aviation fuel. The six cylinder, direct drive engines are equipped with a geared starter, 12 volt 70 ampere alternator, carburetor or fuel injector, diaphragm fuel pump and shielded ignition system.

The engine controls are provided with locks on the throttle and carburetor heat.* In addition, the fuel injected engines have a lock on the mixture control. The push pull controls are located in the lower center of the instrument panel.

Engine mount is of steel tubing construction and incorporates vibration absorbing dynafocal mounts. The all aluminum engine cowl is a cantilever structure, attached at the firewall. Side panels are hinged for quick access to the engine compartment.

The exhaust system consists of dual exhaust stacks and mufflers with exhaust gases directed overboard at the bottom rear of the cowl, on each side of the nose gear. Heat for the cabin heater and defroster is taken from the left muffler shroud. Heat for the carburetor is taken from the right muffler shroud.*

An efficient aluminum oil cooler is mounted on the left front engine baffle. Engine oil drainage is accomplished by a quick drain installed in the right side of the engine sump.

The propeller on the Comanche is a Hartzell HC-C2YK-1A or 1B/8467-7R constant speed, controllable unit. It is controlled entirely by use of the propeller control located in the center of the lower instrument panel.

* WITH CARBURETOR INDUCTION ONLY.

INDUCTION SYSTEM

The Lycoming engine induction system in the Comanche is equipped with a Marvel Schebler model MA-4-5 carburetor or a Bendix RSA-5AD1 fuel injector.

The carburetor installed on the O-540-E engine is of the single barrel float type and is equipped with a manual altitude mixture control and an idle cut-off. Distribution of the fuel-air mixture to each cylinder is obtained by the center zone induction system, which is integral with the oil sump and is submerged in oil, insuring a more uniform vaporization of fuel. From the riser the fuel air mixture is distributed to each cylinder.

The fuel injector installed on the IO-540-D engine is based on the principle of measuring air flow and using the air flow signals to operate a servo valve. The accurately regulated fuel pressure established by the servo valve, when applied across a fuel control (jetting system), makes fuel flow proportional to air flow.

Fuel pressure regulation, by means of the servo valve, necessitates only a minimum fuel pressure drop through the entire metering system. This makes it possible to maintain metering pressure above vapor forming conditions, and at the same time requires a fuel inlet pressure sufficiently low so that a diaphragm pump can be used. An inherent feature of the servo system is self-purging which eliminates any possibility of vapor lock and associated problems of difficult starting.

The injection system consists of a Servo Regulator, which meters fuel flow in proportion to air flow to the engine, giving proper fuel air mixture at all engine speeds, and a Flow Divider, which receives the metered fuel and accurately divides fuel flow to each cylinder Fuel Nozzle.

Installed in the instrument panel is a Fuel Flow Indicator. This instrument is connected to the flow divider and monitors fuel pressure. The instrument converts fuel pressure to an accurate indication of fuel flow in gallons per hour, percentage of cruise power, and proper leaned mixture for take-off at various altitudes.

NOTE

An increasing or abnormally high fuel flow indication is a possible symptom of restricted injector lines or nozzles.

Induction air for either engine enters an opening in the nose cowl below the propeller and is picked up by a large air duct. The air is directed through a filter and on to the carburetor or servo regulator. For the fuel injection installation, located in the air box at the throat of the servo regulator is a spring loaded door which opens automatically if the filter becomes blocked.

STRUCTURES


Structures are of sheet aluminum construction, and are designed to ultimate load factors well in excess of normal requirements. All components are completely zinc chromate primed, and exterior surfaces are coated with acrylic lacquer.

The main spars of the wings are joined with high strength butt fittings in the center of the fuselage, making in effect a continuous main spar. The spars are attached to the fuselage at the side of the fuselage. The wings are also attached to the fuselage at the rear spar and at an auxiliary front spar.

Wing airfoil section is a laminar flow type, NACA-64₂A215, modified with maximum thickness about 40% aft of the leading edge. This permits the main spar, located at the point of maximum thickness, to pass through the cabin under the center seat, providing unobstructed cabin floor space ahead of the center seat.

LANDING GEAR

The nose gear is steerable with the rudder pedals through a 40 degree arc. During retraction of the gear the steering mechanism is disconnected automatically to reduce rudder pedal



Landing Gear Selector Switch

To guard against inadvertent movement of the landing gear selector on the ground, a mechanical guard is positioned just below the selector handle. The handle must also be pulled aft before moving it upward. The gear selector is in the shape of a wheel, to differentiate from the electric flap control knob, which has an airfoil shape. As an added safety feature, the warning horn is connected to the gear selector switch. The horn will operate if the selector is moved to the **UP** position with the master switch on and the weight of the airplane on the landing gear. As a final safety factor to prevent gear retraction on the ground, an anti-retraction switch is installed on the left main gear. This prevents the electric circuit to the landing gear motor from being completed until the gear strut is within three quarter inch of full extension.

A green light on the instrument panel below the landing gear switch is the primary indication that all gears are down and locked. The telescoping emergency gear handle should be used as a secondary indication only.

The warning horn will also sound if power is reduced below approximately 12" of manifold pressure and the gear has not been lowered. As optional equipment, a visual indicator, located on top of the instrument panel, will pop-up if the gear is retracted and power is reduced below 14" manifold pressure. This indicator

loads in flight. The nose gear is equipped with a hydraulic shimmy dampener.

Retraction of the landing gear is accomplished through the use of an electric motor and transmission located under the floorboards, actuating push-pull cables to each main gear and a push-pull tube to the nose gear. The landing gear motor is activated by a selector switch located on the instrument panel.

is operated mechanically by the landing gear and throttle and therefore has no connection with the electrical system.

An amber light above the switch indicates gears up.

THE INDICATION LIGHTS ARE AUTOMATICALLY DIMMED WHEN THE NAVIGATION LIGHTS ARE TURNED ON.


The brakes on the Comanche are actuated by toe brake pedals mounted on the left set of rudder pedals and by a hand lever protruding from under the instrument panel. Hydraulic brake cylinders are located above the left rudder pedals and are accessible in the cockpit for servicing. Parking brake valves are incorporated in each cylinder. Two cables extending from the parking brake "T" handle are attached to the parking brake valves. To prevent inadvertent application of the parking brake in flight, a safety lock is incorporated in the valves, thus eliminating the possibility of pulling out the "T" handle until pressure is applied by use of the toe brakes or the hand lever.

A tow-bar is provided with each aircraft. When not in use it is stored next to the main spar. It may be removed by lifting the flap covering the forward side of the spar and removing the bar from its fasteners.


When towing with power equipment, caution should be used not to turn the nose gear beyond its 20 degree radius from center as this may damage the nose gear and steering mechanism.

CONTROL SYSTEM

The flight controls on the Comanche are the conventional three control type operated by a control column and rudder pedals.



Tow-Bar Storage



Flap And Trim Control

are operated by an electric motor they can be lowered and stopped in any desired position. The flap control switch is located on the nose wheel well just above the rudder trim control. Located on the instrument panel is a flap position indicator which is marked to show the degrees of flap travel. A range for take-off operation is also shown.

Located in the inboard end of the right flap is a lock which holds the flap in the **UP** position so that it can be used as a step for entry or exit. A second lock is incorporated to prevent the flap from going full down in case a step load is applied and the up lock is not fully engaged.

FUEL SYSTEM


The fuel for the Comanche is carried in two rubber-like fuel cells located in the inboard leading edge sections of the wings. Capacity of these cells, which are classified as the main fuel cells is 30 gallons each (28 gallons useable).


As optional equipment for the Comanche, a 30 gallon auxiliary fuel system is available. The system consists of two 15 gallon fuel cells installed in the wings just outboard of the main fuel cells. Use auxiliary fuel in level flight only.

The all movable stabilator, with an anti-servo tab which also acts as a longitudinal trim tab, provides extra stability and controllability with less size, drag and weight.

Provision for directional and longitudinal trim is provided by an adjustable trim mechanism for the rudder and stabilator.

Installed on the Comanche are electrically operated Max-Lift flaps. As the flaps





Fuel Selector And Drain

cated on the engine accessory section. In the event the engine driven fuel pump fails, an electric auxiliary fuel pump is provided. This pump is operated during starting, take-offs, and landings.

The fuel selector and strainer units for the system are located between the front seats. Daily draining of the strainer is accomplished in the cockpit by opening the hinged access door located in the floorboard just aft of the fuel selector valve and moving the quick drain valve handle to full aft position. The general procedure for draining the fuel system is to open the strainer quick drain for a few seconds with the fuel cell selector on one cell, then change fuel selector to the opposite cell and repeat the process. The same process applies to the auxiliary fuel system. Allow enough fuel to flow to clear lines as well as the strainer. Positive fuel flow shut-off can be observed through the clear plastic tube which carries fuel overboard.

Fuel quantity is indicated by an electric gauge located in the instrument cluster. This gauge will indicate the amount of fuel in the cell that is selected. An over-ride system is incorporated so that it is possible to check the amount of fuel available in the remaining cells without moving the selector handle to that cell position. This is accomplished by depressing the red button (located on the fuel selector plate) under the desired fuel cell position. The fuel gauge will indicate the amount of fuel avail-

The cells should be kept full of fuel during storage of the airplane to prevent accumulation of moisture and deterioration of the cells. For storage over ten days without fuel, the cells should be coated with light engine oil to keep the rubber from drying out.

During normal operation the fuel is drawn to the engine from the cells by a mechanically operated fuel pump lo-

able in that cell. When the red button is released the indicating system will return to its normal operation.

When the fuel selector handle is not in a positive selector detent position, more than one fuel port will be open at the same time. It should be ascertained that the fuel selector is positioned in a detent, which can be easily felt when moving the handle through its various positions.


ELECTRICAL SYSTEM

The Comanche electrical system includes a 12 volt 70 amp alternator, providing power at all engine speeds, a transistorized voltage regulator, an over voltage relay and a 35 ampere hour battery. This results in improved performance for radio and electrical equipment and longer battery life.

The voltage regulator and relays are mounted immediately aft of the baggage compartment. Access for service or inspection is obtained through a removable panel located in the right half of the rear cockpit panel. The battery is located in the engine compartment.

Electrical switches are located on the lower left side of the instrument panel. The circuit breakers, located below the electrical switches, automatically break the electrical circuit if an overload should occur. To reset circuit breakers, push in the reset button. It may be necessary to allow approximately two minutes cooling period before resetting breakers. Corrective action should be taken in event of continual circuit breaker popping. It is possible to manually trip the breakers by pulling out on the reset button. The alternator circuit breaker, mounted on the same panel, is of the switch type and should not be opened without consulting the Service Manual for detailed procedure.

Standard electrical accessories, in addition to those already listed, include a geared starter, stall warning indicator, cigar lighter, ammeter and position lights. Glare ban instrument lighting, pitot heat, auxiliary power unit, and anti-collision light are offered as optional accessories. Circuit provisions are made to handle

ELECTRICAL SYSTEM**PA-24-260**

optional communications and navigational equipment.

Operation of the alternator system, as far as visual indication to the pilot, is the same as a standard generator system. The ammeter, located in the upper right corner of the instrument panel, will give a constant indication of battery charge, or discharge in case of a malfunction of the system. Should a malfunction of the voltage regulator occur that would cause a high voltage condition, the over voltage relay will cut the alternator out of the system. Battery power will still be available to the bus bar.


HEATING AND VENTILATING SYSTEM

There are four individual controls provided for regulating the heating, defrosting and ventilating air. The controls are located on the lower right side of the instrument panel in a console panel.

Heated air for the cabin interior is provided by a heater shroud attached to the left exhaust muffler. Fresh air is picked up at the air induction inlet at the front of the cowl and passed through the heater shroud into a control valve for distribution to the cabin.

Warm air for the defroster system is obtained directly from the heater shroud. The amount of air applied to the windshield is regulated with the control in the console. Caution should be used if it is necessary to operate the defroster on the ground as prolonged application of heat to the windshield may cause distortion.


Fresh air for the cabin interior is picked up from



Heating Controls

HEATING & VENTILATING SYSTEM

1. FRESH AIR INLET
2. FRESH AIR OUTLET
3. HEATED AIR INLET
4. HEATED AIR OUTLET
5. DEFROSTER OUTLET
6. CABIN EXHAUST AIR OUTLET
7. CABIN AIR & DEFROSTER CONTROLS
8. CARBURETOR AIR



air inlets in the leading edge of each wing. The air passes through the wings to the wing root area and is discharged into the cabin near the floor just forward of the front seats. In addition, two fresh air scoops are located on the dorsal fin. These provide air for two overhead ventilators in the rear seat area and two front seat ventilators located adjacent to the windshield posts. Cabin air is exhausted through an outlet located above the hat shelf.

VACUUM SYSTEM

Suction for the vacuum operated Gyro instruments with central air filter system is supplied by an engine driven (dry type) vacuum pump.


A vacuum gauge is installed in the instrument panel to provide a constant indication of vacuum source. Suction is indicated on the gauge in inches of mercury; normal operating range is 4.8 to 5.1 inches. The system is controlled by one adjustable regulator, located under the instrument panel. After initial adjustment the regulator will require very little attention.

INSTRUMENT PANEL

The instrument panel in the Comanche is designed to accommodate the customary advanced flight instruments on the left side in front of the pilot and the engine instruments on the right side. Provision for extra instruments is made in both sections. Gyro instruments are shock mounted and all are accessible for maintenance by removing the access panel over the instruments.

The Artificial Horizon and the Directional Gyro in the flight group are vacuum operated through use of a vacuum pump installed on the engine. The Turn and Bank is an electrically operated instrument, controlled by the master switch, and serves as a standby for the Gyros in case of vacuum system failure.

Radio units are installed in the center of the panel. Radio




power supplies are mounted aft of the baggage area.

SEATS

The front and center re-clining seats are adjustable fore and aft to provide comfort for pilot and passengers. Seat backs may be tipped forward to facilitate ease of entry and exit from the aircraft. They are easily removed by taking out the stops at the end of the mounting tracks and sliding the seats off their tracks.

The optional family seat(s) may be removed, allowing for more baggage area and access to the rear fuselage panel by releasing the snap fasteners that attach the seat backs to the hat shelf and turning the wing fasteners at the back of the seat cushions.




Seat Adjustment Handles

BAGGAGE AREA

Maximum weight in the baggage area, including baggage and/or passenger(s) and family seat(s) is 250 pounds, with up to 20 cubic feet of available space. Baggage may be placed in the aircraft through a 19 x 21 inch door or the passenger entrance. Tie-down straps are available for securing baggage when the family seat(s) are not installed.

The baggage door may



Baggage - Emergency Door

also be used as an emergency exit and is opened by holding the inside door knob up and, at the same time, turning the latch clockwise. The baggage door should not be opened in flight as it is difficult to close.

FINISH

All aluminum sheet components of the Comanche are carefully finished inside and outside to assure maximum service life. Both sides of all pieces are alodine treated, and are sprayed with zinc chromate primer. External surfaces are coated with durable acrylic lacquer in attractive high gloss colors. The application of primer to interior surfaces will prevent corrosion of structural and non-structural parts on the inside where there is no access for normal maintenance.

NOTES

SECTION III

OPERATING INSTRUCTIONS

Preflight	22
Starting Engine (Carburetor)	23
Starting Engine (Fuel Injection)	24
Warm-Up and Ground Check	25
Take-Off	27
Stalls	28
Climb	29
Cruising	29
Approach and Landing	30
Stopping Engine	31
Emergency Procedures	32
Mooring	34
Operating Tips	34
Radio Operation	36

SECTION III


OPERATING INSTRUCTIONS

PREFLIGHT

The following safety procedure instructions must become an integral part of the pilot's operational routine and preflight inspection.

Below is an outline for preflighting the Comanche:

1. a. Ignition and master switches are "OFF".
2. a. Check for external damage or operational interference



to the control surfaces, wings or fuselage.

b. Check for snow, ice, or frost on the wings or control surfaces.

3. a. Check fuel supply.

b. Check fuel cell caps and covers for security (adjust caps to maintain a tight seal).

c. Fuel system vents open.

4. a. Landing gear shock struts properly inflated (approximately 2-3/4" piston exposed).

b. Tires satisfactorily inflated and not excessively worn.

c. Cowling, landing gear doors and inspection covers properly attached and secured.

d. Propeller free of detrimental nicks.

e. No obvious fuel or oil leaks.

f. Engine oil at the proper level. (Insure dip stick is properly seated.)

5. a. Windshield clean and free of defects.

6. a. Tow-bar and control locks detached and properly stowed. Check that baggage-emergency door is secured.

7. a. Upon entering the airplane, ascertain that all controls operate normally.

b. Check that the landing gear selector and the other controls are in their proper position.

c. Close and secure the cabin door.

d. Drain the fuel strainer.

e. Check that required papers are in order and in the airplane.

STARTING ENGINE (Carburetor)

1. Fuel selector to the proper tank.

2. Mixture control full in, "RICH" position.

3. Carburetor heat control full in, "COLD" position.

4. Throttle open 1/4 inch.

5. Propeller control full in "INCREASE RPM".

6. Turn master switch to "ON" position.

7. Turn the auxiliary fuel pump switch **"ON"**, listen for pump to operate and note fuel pressure indication.

8. Prime. When engine is cold (under 40° F) prime three to five strokes; if engine is warm do not prime.

NOTE

If the engine is extremely cold, prime three to five strokes then pull the propeller through by hand. Insure the ignition switch is **"OFF"**.

9. Turn all radios **"OFF"**.

10. Check that propeller area is **"CLEAR"**.

11. Turn the ignition switch to the **"START"** position and hold until engine starts. (Limit starter operation to 30 seconds.) When the switch is released it will return to the **"BOTH"** position.

NOTE

If the above procedure does not start the engine, reprime and repeat the process. If the engine is overprimed, open the throttle and turn the engine over with the starter. If the engine still fails to operate, check for malfunctioning of ignition or fuel system.

STARTING ENGINE (Fuel Injection)

Starting Engine When Cold:

1. Open throttle approximately 1/2 inch.
2. Turn on master switch and electric auxiliary fuel pump.
3. Move mixture control to full rich until an indication on the fuel flow meter is noted. (Engine is primed.)

4. Move mixture control to idle cut-off.
 5. Engage starter.
 6. When engine fires, advance mixture control to full rich.
- If engine does not fire within 5-10 seconds, disengage starter and reprime.

Starting Engine When Hot:

1. Throttle open approximately 1/2 inch.
2. Mixture in idle cut-off.
3. Electric auxiliary fuel pump off.
4. Engage starter. When engine fires, advance mixture.

Starting Engine When Flooded:

1. Throttle full open.
2. Mixture in idle cut-off.
3. Electric auxiliary fuel pump off.
4. Engage starter. When engine begins to fire, advance mixture and retard throttle.

Turn electric fuel pump on for take-off, after climb-out. Do not take off with a dead battery as some voltage is needed to excite the alternator.

Starter manufacturers recommend that cranking periods be limited to thirty seconds with a two minute rest between cranking periods. Longer cranking periods will shorten the life of the starter.

WARM-UP AND GROUND CHECK

As soon as the engine starts, the oil pressure should be checked. If no pressure is indicated within thirty seconds, stop the engine and determine the trouble. In cold weather it will take a few seconds longer to get an oil pressure indication.

Warm-up the engine at 800 to 1200 RPM for not more than two minutes in warm weather, four minutes in cold weather. Avoid prolonged idling at low RPM as this practice may result in fouled spark plugs. The magnetos should be checked at 2000

RPM with 15" MP and the propeller in high RPM, the drop not to exceed 125 RPM. The engine is warm enough for take-off when the throttle can be opened without the engine faltering.

The electric fuel pump(s) should be turned off after starting or during warm-up to make sure that the engine driven pump is operating by noting if fuel pressure or fuel flow is maintained. Prior to take-off the electric pump(s) should be turned on again to prevent loss of power during take-off should the engine driven pump fail.

In aircraft with carburetor induction engines, the carburetor heat should be checked during the warm-up to make sure the heat control operation is satisfactory and to clear out the carburetor if any ice has formed. It should also be checked in flight occasionally when outside air temperatures are between 20° F and 70° F to see if icing is occurring in the carburetor. In most cases when an engine loses manifold pressure without apparent cause, the use of carburetor heat will correct the condition.

When carburetor heat is applied, cold air entering the induction system is taken from the engine compartment, through the exhaust muffler shroud, then to the carburetor; it is not filtered. For this reason carburetor heat should not be used on the ground in dusty conditions except momentarily during the run-up. Dust taken into the intake system can damage the engine severely, and caution must always be exercised during ground operation to prevent dust from entering the engine.

The propeller control should be moved through its complete range during the warm-up to check for proper operation, then left in the full high RPM position. During cold weather operation the propeller should be cycled a minimum of three times to insure that warm engine oil has circulated throughout the entire system.

During the propeller check, as during other ground operations, care must be taken not to run-up the engine with the propeller over loose stones, cinders or other objects which can be picked up by the propeller, and which frequently cause extensive damage to the propeller blades.

TAKE-OFF

Just before take-off the following should be checked:

- | | |
|------------------------|----------------------------|
| 1. Controls free | 6. Carburetor heat "OFF" * |
| 2. Flaps set | 7. Fuel on proper tank |
| 3. Tab set | 8. Electric fuel pump "ON" |
| 4. Propeller set | 9. Engine gauges normal |
| 5. Mixture set (rich*) | 10. Door locked |

* Carburetor induction system only.

In a smooth, steady motion of the throttle apply full power allowing the aircraft to accelerate in the three point attitude until the control surfaces become effective. Then apply slight back pressure on the control column to lift the nose wheel. Under normal take-off conditions the Comanche will leave the ground at about 65 MPH. Trying to pull the aircraft off before the proper speed is obtained will only prolong the take-off run. After the take-off has proceeded to the point at which a landing could no longer be made with the wheels down in the event of power failure, the gear should be retracted. As soon as the gear is up and sufficient altitude has been gained, reduce power to climb setting.

For a minimum take-off run the flaps should be lowered to the recommended 15 degrees. With the flaps in this position, the take-off run will be reduced approximately 20 per cent.

Normally flaps are not used during crosswind take-offs. It is desirable to hold the nose wheel on the runway until a higher than normal take-off speed is obtained, then apply a definite but not abrupt back pressure to the control column to lift the aircraft from the runway. Once airborne, set up the required crab angle, retract the gear at a safe altitude, and continue the climb-out.

During cold weather operation, when taking off from slush or water covered runways, allow the gear to remain down longer than usual so that any slush remaining on the gears will freeze and be broken away when the gear is retracted.

In aircraft with fuel injection, during a normal take-off with

full rich mixture the pointer on the fuel flow meter will stabilize between the sea level mark and the red line. This setting gives a slightly rich mixture to aid in fuel cooling the engine and is recommended for all normal take-offs at sea level.

When taking off from a high altitude field (example 4,000 feet), the mixture should be leaned to obtain maximum power. This is done during the pre-take-off check. Apply full throttle, then move mixture control towards the lean position until the fuel flow pointer has stabilized at the 4,000 foot mark, located between the 19-1/2 and 20 gallon marks. Leave the mixture in this position and proceed with the take-off. Caution should be used when operating with the mixture leaned so that the engine is not overheated.

STALLS

All controls are effective at speeds down through the stalling speed, and stalls are gentle and easily controlled.

STALL SPEED TABLE	
Configuration	(Power Off)
Gear and Flaps Up	75 MPH Calibrated Airspeed
Gear and Flaps Down (Full)	67 MPH Calibrated Airspeed
These figures are at gross weight of 3100 lbs.	

CLIMB

The best rate of climb speed at gross weight will be obtained at 111 MPH. The best angle of climb may be obtained at 87 MPH. At lighter than gross weight these speeds are reduced somewhat. For climbing enroute a speed of approximately 130 MPH is recommended. This will produce better forward speed and increase visibility over the nose during the climb.

CRUISING

The cruising speed of the Comanche is determined by many factors including power setting, altitude, temperature, weight, and equipment installed.

The normal recommended economy cruising power setting of the Comanche is at 65% power. At 10,800 feet this gives a True Airspeed of 176 MPH. This power setting is obtained under standard conditions at 2400 RPM and full throttle. Fuel consumption is approximately 12.7 gallons per hour total.

The optimum cruising speed of the Comanche at 7000 ft. is 182 MPH. (See Power and Performance charts for power settings and performance under various conditions.)

The Lycoming engine in the Comanche can be cruised at any percent of power from 75% down. 2400 RPM is recommended for maximum cruise performance and lower RPM's, down to 1800, for more economical cruising conditions. Ordinarily an RPM setting should be selected which will give maximum smoothness.

To obtain the desired power set the manifold pressure and RPM according to the power setting table in this manual. After the desired power settings have been set up, adjust the mixture control.

Fuel injection engines best power setting is indicated by the fuel flow meter. The low side of the power setting, as shown on the fuel flow meter, indicates best economy for that percent of power while the high side indicates best power. During climbing operation the servo regulator will sense the change in

altitude and will automatically lean the mixture. For better economy manual leaning with the mixture control can also be accomplished.

Use of the mixture control in cruising flight reduces fuel consumption significantly, especially at higher altitudes. The mixture should always be leaned during cruising operation over 5000 feet altitude, and at lower altitudes at the pilot's discretion.

The continuous use of carburetor heat during cruising flight reduces power and performance. Unless icing conditions in the carburetor are severe, do not cruise with the heat on. Apply heat slowly and only for a few seconds at intervals determined by icing severity.

In order to keep the airplane in best lateral trim during cruising, the fuel should be used alternately from each tank. If auxiliary tanks are installed, it is suggested that the fuel in the two auxiliary tanks be used first.

APPROACH AND LANDING

Before landing check list:

1. Fuel selector on proper tank.
2. Mixture **"RICH"**.
3. Propeller set.
4. Carburetor heat **"OFF"*** (unless icing conditions exist).
5. Electric fuel pump **"ON"**.
6. Landing gear **"DOWN"**. (Under 150 MPH check green light **"ON"**, warning horn **"OFF"**, gear emergency handle in **"FORWARD"** position.)
7. Flaps as desired (under 125 MPH).

* Carburetor induction system only.

During the approach, the landing gear can be lowered at speeds under 150 MPH, preferably on the downwind leg. The airplane should be trimmed to approach speed of about 85 MPH and flaps extended. The flaps can be lowered at speeds up to

125 MPH, if desired. The propeller should be set at full RPM or at a high cruising RPM to facilitate an emergency go-around if needed.

The amount of flap used during landings and the speed of the aircraft at contact should be varied according to the wind, the landing surface, and other factors. It is always best to contact ground at the minimum practicable speed consistent with landing conditions.

Normally, the best technique for short and slow landings is to use full flap and a small amount of power, holding the nose up as long as possible before and after ground contact. In high wind conditions, particularly in strong crosswinds, it may be desirable to approach the ground at higher than normal speeds with partial or no flap.

Maximum braking effect during short field landings can be obtained by holding full back on the control wheel with flaps up while applying brakes. This forces the tail down and puts more load on the main wheels, resulting in better traction.

On aircraft with a carburetor installed, carburetor heat should not be applied unless there is indication of carburetor icing, since the use of carburetor heat causes a loss in engine power which may be crucial in the event of a go-around, and can induce detonation in this situation.

STOPPING ENGINE

The flaps should be raised and the electric fuel pump turned off at the pilot's discretion. After parking, the radios should be turned off, the propeller set at minimum blade angle, and the engine stopped by pulling the mixture control out to idle cut-off. The throttle should be left full aft to avoid engine vibration while stopping. Then the ignition and master switches must be turned off and the parking brake set.

EMERGENCY PROCEDURES**Manual Gear Extension:**

Manual landing gear extension is accomplished with the telescoping lever located directly aft of the nose wheel housing. This control is used to extend the gear if the electrical actuating system has failed. The gear will not stay up if retracted manually.

Before proceeding with the emergency extension check the following:

1. Gear circuit breakers are in.
2. Master switch is on.
3. Navigation lights are off (daytime).


To extend the gear, remove the cover over the emergency disengage control located between the two front seats, and follow the instructions on the back of this cover as follows:

1. Airspeed not over 100 MPH.
2. Landing gear switch in the "Gear Down Locked" position.
3. Disengage electric motor by pushing motor release arm forward through full travel.
4. Extend emergency handle to full length.
5. Push handle forward full travel to extend the landing gear.

After the gear has been extended manually, do not perform any unnecessary operation to the gear until the aircraft is placed on jacks.

To return the system to normal electric operation, re-engage the electric motor to the landing gear extension torque tube by following the procedure given:

1. Circuit breaker should be disengaged.
2. Pull landing gear emergency extension handle about half way back, allowing gear to hang partially extended.



Emergency Gear Extender

3. Engage circuit - master switch off.

4. With master and selector switches move the end of the electric motor drive shaft into position about half way back so that the slot in the drive shaft is near the mating pin on the torque tube.

5. Using the extension handle move the torque tube pin slightly back and forth until it can be engaged with the drive shaft slot, then push the parts together.

6. Lock the drive shaft to the torque tube by pulling the motor release arm full back to the normal locked position.

Gear-Up Landing:

A gear-up landing should only be made during an emergency (1) when the surface is too soft or rough to permit a gear-down landing, (2) when a field is too short for a gear-down landing, which might cause more damage through hitting obstructions than the gear-up landing would cause, (3) when a water landing is necessary.

In the event of a gear-up landing, make a normal approach as with gear-down, leave flaps up (to reduce flap and wing damage); close the throttle and cut the master and ignition switches during the flare out, turn the fuel selector off, and contact the ground at minimum speed.

Engine Failure:

The most common cause of engine failure is mismanagement or malfunction of the fuel system. Therefore, the first step to take after engine failure is to move the fuel selector valve to the tank not being used. This will often keep the engine running even if there is no apparent reason for the engine to stop on the tank being used.

If changing to another tank does not restore the engine:

1. Check fuel pressure and turn on electric fuel pump, if off.
2. Push mixture control to full "RICH".
3. Apply carburetor heat (carburetor installation).
4. Check ignition switch.

MOORING

The Comanche should be moved on the ground with the aid of the nose wheel tow-bar provided with each plane and stored on the front spar.

Tie-down ropes for mooring the airplane can be fastened to the wing tie-down rings and the tail skid.

The aileron and elevator controls should be secured by means of the safety belt to prevent control surface damage. The rudder is held in position by its connections with the steerable nose wheel and does not need to be secured except under unusually high wind conditions.

OPERATING TIPS

In the operation of the Comanche, as in that of any other type of aircraft, there are a few points of technique and information that apply particularly to this model. The following Operating Tips may be helpful in the operation of the Comanche:

1. Remember that when the navigation lights are on, the gear position lights are dim.
2. Learn to trim the airplane for take-off so that only a very light back pressure on the wheel is required to lift the ship off the ground.
3. On take-off; do not retract the gear prematurely. The aircraft may settle and make contact with the ground because of lack of flying speed, atmospheric conditions or rolling terrain.
4. The best speed for take-off is at about 65 MPH under normal conditions. Trying to pull the airplane off the ground at too low an airspeed will increase the take-off roll rather than decrease it.
5. Although it is permissible to extend the landing gear at speeds up to 150 MPH, the loads on the landing gear extension motor and on the gear doors are much lower if slower speeds are used. For this reason, it is recommended that unless there is a

good reason to lower the gear at a higher speed, it should normally be extended at speeds below 125 MPH.

6. The flaps can be lowered at airspeeds up to 125 MPH. To reduce flap operating loads, however, it is desirable to slow the airplane to 100 MPH or less before extending the flaps. At these reduced speeds, the load applied to the flaps is greatly reduced.

7. If the flap actuating mechanism is not properly maintained it is possible for one or both flaps to remain down. Therefore, in extending or retracting the flaps, it is recommended to do so in steps to avoid undesirable roll due to asymmetric flaps. If one flap sticks down the other can usually be controlled so that the pilot can achieve symmetric positions.

8. During gear operation keep the floor area under the emergency gear lever clear. Restriction to movement of the lever will cause the gear motor circuit breaker to open.

9. Always ascertain position of landing gear by the position of the emergency gear lever as well as the gear position lights.

10. If, under unusual circumstances, the landing gear motor is apparently overloaded and the circuit breaker opens repeatedly, the electric motor can be assisted by applying light hand pressure to the emergency gear lever.

11. Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.

12. When landing and upon making contact with the ground on the main wheels, neutralize the rudder pedals, apply additional back pressure to the control wheel and retract the flaps. This gives best directional control on the ground and provides for full effectiveness of the brakes during the landing roll.

13. In some instances when operating with fuel injection at altitudes over 10,000 feet, surging of the engine may be experienced. This condition may be eliminated by proper leaning of the mixture or by use of the electric fuel pump.

14. A high fuel pressure indication of the fuel flow indicator is a possible indication of restricted air bleed nozzles.

15. The shape of the wing fuel tanks is such that in certain maneuvers the fuel may move away from the tank outlet. If the outlet is uncovered, the fuel flow will be interrupted and a temporary loss of

Prolonged slips or skids in any pitch attitude or other unusual or abrupt maneuvers which could cause uncovering of the fuel outlet must be avoided.

RADIO OPERATION

Communication and navigational equipment controls are located in the center of the instrument panel. Associated auxiliary switches are located on a separate panel below the control column on the lower right side of the instrument panel. Circuit breakers for the radios are located to the left of the main switch panel.

All sets are turned "ON" by the switch located on the control head of each particular unit, with the exception of the marker beacon and glide slope power switches which are located on the Audio Selector Switch Panel.

After power is supplied, the pilot may wish to operate one of the two transmitters by moving the transmitter selector switch to the proper position. The switch is located on the selector switch panel.

A separate three position audio selector switch is provided for each receiver. Each receiver audio output may be connected to either the speaker or the headset. In addition, they may be placed on the "OFF" or standby position. To receive audio through the speaker from the Marker Beacon and DME the top Mark 12 must be in operation. Power from this radio is not required when the headphones are connected to the Marker Beacon or DME.


Two or more sets may be simultaneously connected to either the headset or speaker position by placing the selector switches in the desired combination. For example, the A.D.F. and the top Mark 12 may be selected to operate on the speaker and the lower Mark 12 may be selected for headset operation. If desired the pilot may listen to the speaker and the copilot the headset.

SECTION IV


PERFORMANCE CHARTS

Take-off Distance over 50 Foot Barrier	37
Take-off Ground Run Distance	38
Speed For Best Rate and Angle of Climb	39
Climb Rate vs Standard Altitude and Weight	40
True Airspeed vs Altitude	41
Range vs Standard Altitude	42
Landing Distance over 50 Foot Barrier	43
Landing Ground Roll	44
Altitude Conversion Chart	45
Power Setting Table, Lycoming O-540-E	46
Power Setting Table, Lycoming IO-540-D	47
Part Throttle Fuel Consumption, IO-540-D	48
Fuel Flow Indicator, Lycoming IO-540-D	49


PA-24-260 COMANCHE




PA-24-260 COMANCHE




**PA-24-260
COMANCHE**




PA-24-260 COMANCHE




PA-24-260 COMANCHE




PA-24-260 COMANCHE




PA-24-260 COMANCHE



PA-24-260 COMANCHE



PA -24 -260 COMANCHE



Power Setting Table - Lycoming Model O-540-E, 260 HP Engine


Press. Alt Feet	Std Alt Temp ° F	143 HP - 55% Rated RPM AND MAN. PRESS.				169 HP - 65% Rated RPM AND MAN. PRESS.				195 HP - 75% Rated RPM AND MAN. PRESS.				Press. Alt Feet
		2100	2200	2300	2400	2100	2200	2300	2400	2200	2300	2400	2500	
SL	59	21.7	20.8	20.2	19.5	24.6	23.6	22.7	21.9	26.3	25.3	24.4	23.8	SL
1,000	55	21.5	20.6	20.0	19.3	24.4	23.3	22.5	21.7	26.0	25.0	24.1	23.5	1,000
2,000	52	21.3	20.4	19.8	19.1	24.1	23.1	22.2	21.5	25.7	24.8	23.9	23.3	2,000
3,000	48	21.0	20.1	19.6	18.9	23.8	22.9	22.0	21.2	25.4	24.5	23.6	23.0	3,000
4,000	45	20.8	19.9	19.4	18.7	23.6	22.6	21.8	21.0	25.1	24.2	23.3	22.7	4,000
5,000	41	20.6	19.7	19.2	18.4	23.3	22.4	21.5	20.8	24.8	23.9	23.0	22.5	5,000
6,000	38	20.4	19.5	18.9	18.2	23.1	22.2	21.3	20.6	-	23.7	22.8	22.2	6,000
7,000	34	20.2	19.3	18.7	18.0	22.8	22.0	21.1	20.4	-	-	22.5	22.0	7,000
8,000	31	20.0	19.1	18.5	17.8	22.6	21.8	20.8	20.1	-	-	22.3	21.7	8,000
9,000	27	19.8	18.8	18.3	17.6	-	21.6	20.6	19.9	-	-	-	-	9,000
10,000	23	19.6	18.6	18.1	17.4	-	-	20.3	19.7	-	-	-	-	10,000
11,000	19	19.4	18.4	17.9	17.2	-	-	-	19.5	-	-	-	-	11,000
12,000	16	19.2	18.2	17.7	17.0	-	-	-	19.3	-	-	-	-	12,000
13,000	12	-	17.9	17.4	16.8	-	-	-	-	-	-	-	-	13,000
14,000	9	-	17.7	17.2	16.6	-	-	-	-	-	-	-	-	14,000
15,000	5	-	-	17.0	16.4	-	-	-	-	-	-	-	-	15,000


To maintain constant power, correct manifold pressure approximately 0.17" Hg for each 10° F variation in carburetor air temperature from standard altitude temperature. Add manifold pressure for air temperatures above standard; subtract for temperatures below standard.

Power Setting Table - Lycoming Model 10-540-D, 260 HP Engine

Press. Alt Feet	Std Alt Temp ° F	143 HP - 55% Rated RPM AND MAN. PRESS.				169 HP - 65% Rated RPM AND MAN. PRESS.				195 HP - 75% Rated RPM AND MAN. PRESS.				Press. Alt Feet
		2100	2200	2300	2400	2100	2200	2300	2400	2100	2200	2300	2400	
SL	59	22.3	21.5	20.7	19.8	25.3	24.1	23.2	22.2	26.9	25.8	24.8	24.0	SL
1,000	55	22.1	21.3	20.5	19.6	25.1	23.9	22.9	22.0	26.6	25.5	24.5	23.7	1,000
2,000	52	21.9	21.0	20.3	19.4	24.8	23.6	22.7	21.8	26.3	25.3	24.3	23.5	2,000
3,000	48	21.7	20.8	20.0	19.2	24.5	23.4	22.5	21.6	26.0	25.0	24.0	23.2	3,000
4,000	45	21.4	20.6	19.8	19.0	24.2	23.1	22.2	21.4	25.7	24.7	23.8	22.9	4,000
5,000	41	21.2	20.3	19.6	18.8	24.0	22.9	22.0	21.1	25.4	24.4	23.5	22.7	5,000
6,000	38	21.0	20.1	19.4	18.6	23.7	22.6	21.7	20.9	—	24.1	23.3	22.4	6,000
7,000	34	20.7	19.9	19.1	18.4	23.5	22.4	21.5	20.7	—	—	23.0	22.2	7,000
8,000	31	20.5	19.6	18.9	18.2	—	22.1	21.2	20.5	—	—	—	21.9	8,000
9,000	27	20.3	19.4	18.7	18.0	—	21.9	21.0	20.3	—	—	—	—	9,000
10,000	23	20.0	19.2	18.5	17.7	—	—	20.7	20.0	—	—	—	—	10,000
11,000	19	19.8	18.9	18.2	17.5	—	—	—	19.8	—	—	—	—	11,000
12,000	16	19.6	18.7	18.0	17.3	—	—	—	—	—	—	—	—	12,000
13,000	12	—	18.5	17.8	17.1	—	—	—	—	—	—	—	—	13,000
14,000	9	—	—	—	16.9	—	—	—	—	—	—	—	—	14,000
15,000	5	—	—	—	16.7	—	—	—	—	—	—	—	—	15,000

To maintain constant power, correct manifold pressure approximately 0.17" Hg for each 10° F variation in carburetor air temperature from standard altitude temperature. Add manifold pressure for air temperatures above standard; subtract for temperatures below standard.





READING THE FUEL FLOW INDICATOR

PA-24-260

SECTION V

MAINTENANCE

Tire Inflation	50
Battery Service	50
Brake Service.	51
Landing Gear Service	51
Fuel and Oil Requirements	54
Leveling and Rigging	55
Care of Air Filter	56
Care of Windshield and Windows.	56
Serial Number Plate	57
Fuel System	57

SECTION V

MAINTENANCE

This section of the Comanche Handbook contains information which pertains to minor maintenance of the airplane. Any complex repair or modification should be accomplished by a Piper Certified Service Center or equivalent.


TIRE INFLATION

For maximum service from the tires on the Comanche, keep tires inflated to the proper pressure of 42 lbs. on the main wheels and 27 lbs. on the nose wheel. Interchange the tires on the wheels if necessary to produce even wear. All wheels and tires are balanced before original installation, and the relationship of tire, tube and wheel should be maintained whenever possible upon reinstallation. Out of balance wheels can cause extreme vibration in the landing gear during take-off. In the installation of new components, it may be necessary to rebalance the wheels with the tires mounted.

BATTERY SERVICE

Access to the 12-volt 35 ampere hour battery is through the engine right access panel.

The battery should be



Battery Installation

checked frequently for proper fluid level, but must not be filled above the baffle plates. All connections must be clean and tight.

The battery and battery box should be removed periodically and checked for corrosion. Corrosion effects may be neutralized by applying a solution of baking soda and water, allowing no soda solution to enter the battery. Wash battery and box with clean water and dry.

If the battery is not up to proper charge, recharge starting with a charging rate of 4 amps and finishing with 2 amps. Quick charges are not recommended.

BRAKE SERVICE

The brake system is filled with MIL-H-5606 (petroleum base) hydraulic brake fluid. This should be checked at every 50 hour inspection and replenished when necessary, refilling the brake reservoir on the firewall to the indicated level.

No adjustment of brake clearances is necessary on the Comanche brakes. If after extended service the brake blocks become worn excessively, they are easily replaced with new brake segments.

To remove the brake disc, lining and backing plate, remove the four bolts through the brake housing, then the main wheels are easily removed by taking off the axle nut and withdrawing the wheel from the axle.

Tires are dismounted from the wheels by deflating the tube, then removing the wheel through-bolts, allowing the wheel halves to be separated.

LANDING GEAR SERVICE

In jacking up the Comanche for landing gear and other service, a jack kit (available through the Piper Aircraft Distributor Service Departments) should be used. This kit includes two hydraulic jacks and a tail support. Approximately 300 lbs. of ballast should be placed on the base of the tail support before jacking up the airplane.

LUBRICATION CHART

HOURS	LUBRICANT	LUBRICANT	HOURS
RUDDER HINGES AND HORN	100	STABILATOR TRIM PULLEYS (SEE CAUTION 4)	250
STABILATOR TRIM TAB	100	CONTROL COLUMN	100
STABILATOR ADJUSTMENT MECHANISM	100	BRAKE RESERVOIR, MAINTAIN FLUID LEVEL INDICATED ON THE SIDE OF RESERVOIR	30
STABILATOR CONTROL PULLEYS	100	RUDDER ADJUSTMENT MECHANISM	100
BAGGAGE DOOR AND MAIN DOOR HINGES	100	SEAT ADJUSTMENTS	100
FLAP TRACKS (SEE NOTE 7)	100	NOSE WHEEL STEERING	100
AILERON HINGES, FLAP ROLLERS, PULLEY AND BELLCRANK RIGHT AND LEFT	100	INDUCTION AIR FILTER (SEE NOTE 6)	50
HINGES—MAIN GEAR DOORS, EACH	100	PROPELLER GREASE FITTINGS, 4 TOTAL	100
MAIN LANDING GEAR GREASE FITTINGS RIGHT AND LEFT, 6 EACH	100	NOSE GEAR GREASE FITTING, 6 TOTAL	100
MAIN WHEEL BEARINGS RIGHT AND LEFT	100	UPPER AND LOWER TORQUE LINK CONNECTING BOLT	100
LANDING GEAR FLAP RETRACTION SYSTEM (SEE NOTE 2)	500	DRAG LINK GREASE FITTINGS, 5 TOTAL	100
ENGINE OIL TANK, DRAIN AND FILL 12 QT. CAPACITY	50	NOSE WHEEL BEARING	100
	ENGINE	HINGES—NOSE WHEEL DOOR, 2 TOTAL	100
		RETRACTION PUSH-PULL ROD END FITTING	100

NOTES

- FUEL SYSTEM—THE FOLLOWING POINTS REQUIRE REGULAR SERVICING—FUEL PUMP STRAINER—INJECTOR SCREEN—FILTER BOWL—QUICK DRAIN UNIT.
- LANDING GEAR RETRACTION SYSTEM—WHEN REASSEMBLING TRANSMISSION, FILL TRANSMISSION 1/2 PULL OF "GEAR AND ACTUATOR GREASE" SPECIFICATION MIL-G-23827 or MIL-G-77118. APPLY THIN COATING OF "GEAR AND ACTUATOR GREASE" TO RETRACTION SCREW AFTER CLEANING EVERY 500 HOURS.
- LANDING GEAR STRUTS—FOLLOW INSTRUCTION PLACARD ON OLEO STRUT.
- MISCELLANEOUS—DURING ROUTINE MAINTENANCE CHECKS, APPLY LUBRICATION TO MISCELLANEOUS LINKAGES.
- BATTERY—CHECK BATTERY FLUID LEVEL, & BATTERY CONDITION EVERY 25 HOURS.
- CLEAN PAPER AIR FILTER BY TAPPING THE UNIT LIGHTLY AGAINST A HARD SURFACE. DO NOT USE SOLVENT OR COMPRESSED AIR.
- LUBRICATE FLAP TRACKS WITH DUPONT'S ALL PURPOSE SLIP SPRAY #6611.

LEGEND

◇	MIL-G-23827	GREASE—GEAR AND ACTUATOR
✓	MIL-G-77118	OIL—GENERAL PURPOSE LOW
△	MIL-L-7870	TEMP. LUBRICATION
□	MIL-L-7711	GREASE—LUBRICATION GENERAL
○	MIL-L-3545	PURPOSE AIRCRAFT
✱	MIL-G-3278	GREASE—AIRCRAFT HIGH
○	MIL-H-5606	TEMPERATURE
		GREASE—AIRCRAFT AND
		INSTRUMENTS
		HYDRAULIC FLUID (RED)
ENGINE	SAE 50 ABOVE 40° F AIR TEMP	
	SAE 40 BETWEEN 30° F AND 50° F AIR TEMP	
	SAE 30 BETWEEN 10° F AND 30° F AIR TEMP	
	SAE 20 BELOW 10° F AIR TEMP	

CAUTIONS

- DO NOT USE A HYDRAULIC FLUID WITH A CASTOR OIL OR ESTER BASE.
- DO NOT OVER-LUBRICATE PEDAL CONTROL.
- DO NOT APPLY LUBRICANT TO RUBBER PARTS.
- UNDER NO CIRCUMSTANCES SHOULD THE CABLES FROM THE COCKPIT TO THE REAR OF THE FUSELAGE BE LUBRICATED—AS THIS MAY CAUSE SLIPPAGE.
- REMOVE ALL EXCESS GREASE FROM GREASE FITTINGS.

SEE LYCOMING SERVICE INSTRUCTIONS
NO. 1014 FOR USE OF DETERGENT OIL.

Landing gear oleos on the Comanche should be serviced according to instructions on the units. All three oleos should be extended until about 2-3/4 inches of oleo piston tube is exposed under static load.

To add air to the oleo struts, a strut pump is attached at the air valve and the oleo pumped up to the proper position. To add oil, jack the aircraft, release the air through the strut valve and allow the strut to extend fully. Next remove the air valve and fill the unit through this opening. Then compress the oleo to within 1/4 inch of full compression, allowing air and excess oil to escape. Then reinsert the valve core and pump up the strut.

FUEL AND OIL REQUIREMENTS

Aviation Grade 91/96 Octane (minimum) fuel must be used in the Comanche. The use of lower grades of fuel can cause serious engine damage in a very short period of time and is considered of such importance that the engine warranty is invalidated by such use.

The oil capacity of the Lycoming O-540-E or IO-540-D is 12 quarts and the minimum safe quantity 2-3/4 quarts. The operating oil level is normally kept a quart or more below the maximum to reduce oil consumption. It is recommended that engine oil be changed every 50 hours or sooner under unfavorable conditions. The following grades are required for the specified temperatures:

Temperatures above 60° F	S.A.E. 50
Temperatures between 30° F and 90° F	S.A.E. 40
Temperatures between 0° F and 70° F	S.A.E. 30
Temperatures below 10° F	S.A.E. 20

LEVELING AND RIGGING


Leveling the Comanche for purposes of reweighing or rigging is accomplished as follows:

1. Partially withdraw the two machine screws on the side of the fuselage located one fore and one aft of the right rear window. These screws are leveling points and the airplane is longitudinally level when a level placed on the head of these screws indicates level.


2. To put the airplane in a longitudinally level position on scales, first block the main gear oleos to full extension, then deflate the nose wheel tire until the proper position is reached. For rigging purposes, place airplane on jacks.

3. To level the airplane laterally, place a level on or parallel to the hat section channel of the firewall. (Even length spacers may be used to bring the level above any obstacles in the area of the channel.)

Rigging: Although the fixed flight surfaces on the Comanche cannot be adjusted in position for rigging purposes, it may be necessary on occasions to check the position of these surfaces. The movable surfaces all have adjustable stops as well as adjustments on their cables or push-pull connections so that their



Longitudinally Leveling



Laterally Leveling

range of movement can be altered. The positions and travels of the various surfaces are as follows:

1. Wings: 5° dihedral, no twist.
2. Stabilator: No dihedral, travel $-14^{\circ} \pm 1^{\circ}$ up, $4^{\circ} \pm 1^{\circ}$ down.
3. Fin: Should be vertical and in line with center of fuselage.
4. Ailerons: Travel $19^{\circ} \pm 2^{\circ}$ up, $15^{\circ} \pm 2^{\circ}$ down.
5. Flaps: Travel $-32^{\circ} \pm 1^{\circ}$ full down.
6. Rudder: Travel 25° left or right, $\pm 2^{\circ}$.
7. Horizontal Tail Tab Travel: $7^{\circ} \pm 1^{\circ}$ up, $15^{\circ} \pm 1^{\circ}$ down.
8. Stabilator Tab Ratio: $1\frac{1}{2}:1$

For purposes of changing the lateral trim, fixed tabs are provided on the ailerons which can be adjusted as necessary.

CARE OF AIR FILTER

The induction air filter must be cleaned at least once every fifty hours and depending on the type of condition existing, it may be necessary to clean the filters daily or every five hours. Extra filters are inexpensive and should be kept on hand and used for rapid replacement.

The following cleaning procedure is recommended by the manufacturer of the filter:

1. Remove air scoop.
2. Remove filter from cowl.
3. Tap gently to remove dirt particles. Do not use compressed air.
4. Reassemble to cowl and replace scoop.

CARE OF WINDSHIELD AND WINDOWS

A certain amount of care is required to keep the plexiglas windows clean and clear. The following procedure is recommended:

1. Flush with clean water and dislodge excess dirt, mud, etc., with your hand.

2. Wash with mild soap and warm water. Use a soft cloth or sponge. Do not rub.
3. Remove oil, grease or sealing compounds with a cloth soaked in kerosene.
4. After cleaning, apply a thin coat of hard polishing wax. Rub lightly with a soft dry cloth.
5. A severe scratch or mar can be removed by using jeweler's rouge to rub out scratch, smooth on both sides and apply wax.

SERIAL NUMBER PLATE

The serial number plate is located outside of fuselage to the left of the tail skid. The serial number of the plane should always be used in referring to the airplane in service or warranty matters.

FUEL SYSTEM

The fuel screens in the strainer, the carburetor injector screen and fuel nozzles will require cleaning at the first 25 hour inspection and every 50 hour inspection thereafter. The screen in the carburetor and injector is located in the housing where the fuel inlet line connects to the injector. The fuel strainer located under the floorboards is accessible for cleaning through an access plate on the bottom of the fuselage. When reassembling the strainer after cleaning, a small amount of grease applied to the gasket will facilitate assembly. Acetone is recommended for cleaning these screens.

NOTES

INDEX

SECTION I	Page
Specifications:	1
Performance	1
Weights	2
Power Plant	2
Fuel	2
Baggage	2
Dimensions	3
Landing Gear	3
 SECTION II	
Design Information:	5
Engine and Propeller	5
Induction System	6
Structures	7
Landing Gear	7
Control System	9
Fuel System	10
Electrical System	13
Heating and Ventilating System.	15
Vacuum System	17
Instrument Panel	17
Seats	19
Baggage Area	19
Finish.	20
 SECTION III	
Operating Instructions:	22
Preflight	22
Starting Engine (Carburetor).	23
Starting Engine (Fuel Injection)	24
Warm-Up and Ground Check	25

INDEX (cont)

SECTION III (cont)	Page
Take-Off	27
Stalls	28
Climb	29
Cruising	29
Approach and Landing	30
Stopping Engine	31
Emergency Procedures	32
Mooring	34
Operating Tips	34
Radio Operation	36
 SECTION IV	
Performance Charts:	37
Take-off Distance over 50 Foot Barrier	37
Take-off Ground Run Distance	38
Speed For Best Rate and Angle of Climb	39
Climb Rate vs Standard Altitude and Weight	40
True Airspeed vs Altitude	41
Range vs Standard Altitude	42
Landing Distance over 50 Foot Barrier	43
Landing Ground Roll	44
Altitude Conversion Chart	45
Power Setting Table, Lycoming O-540-E.	46
Power Setting Table, Lycoming IO-540-D	47
Part Throttle Fuel Consumption, IO-540-D	48
Fuel Flow Indicator, Lycoming IO-540-D	49
 SECTION V	
Maintenance:	50
Tire Inflation	50
Battery Service	50

INDEX (cont)

SECTION V (cont)	Page
Brake Service	51
Landing Gear Service	51
Fuel and Oil Requirements	54
Leveling and Rigging	55
Care of Air Filter	56
Care of Windshield and Windows	56
Serial Number Plate	57
Fuel System	57

